

Parts List - 33-76 Variable Displacement Pump



REF#	DESCRIPTION	REF#	DESCRIPTION
1	RETAINING RING	57	NAMEPLATE
2	O-RING	58	TYPE "U" DRIVE SCREW
3	O-RING	59	TRUNNION HEX HEAD BOLT
4	SEAL RETAINER PIN S/A	60	TRUNNION
5	SEAL SPRING	61	TRUNNION BEARING
6	O-RING	62	O-RING
7	STATIONARY SEAL	63	TRUNNION BEARING SHIM PACK
8	ROTATING SEAL	64	O-RING PLUG S/A
9	SHAFT SEAL KIT	65	O-RING PLUG S/A
10	SPACER FOR 76 SHAFT SEAL	66	VARIABLE HOUSING
11	IN 33-54 FRAME	67	END COVER GASKET
12	HEX HEAD BOLT	68	END COVER BEARING KIT
13	SHIPPING STRAP	69	SHAFT SHIM PACK
14	MOUNTING FLANGE	70	SPRING BOX
15	DOWEL	71	O-RING
16	MOUNTING FLANGE GASKET	72	IPOR SHIM KIT
17	MOUNTING FLANGE BEARING	73	SPRING
18	RETAINING RING	74	SPRING SPACER
19	INPUT SHAFT	75	VERRIDE SPOOL
20	CLEVIS PIN LINKAGE	76	END COVER, 1", CODE 61
21	C-CLIP	77	O-RING PLUG S/A
22	CONTROL LINK	78	O-RING PLUG S/A
24	EXTERNAL RETAINING RING	79	NEEDLE ROLLER, 5/32 DIAMETER
25	LINKAGE PIN	80	NEEDLE ROLLER, 5/32 DIAMETER
26	LINKAGE PIN KIT	81	O-RING PLUG S/A
27A	THRUST PLATE, THIN	82	ORIFICE
27B	THRUST PLATE, THICK	83	CHECK VALVE, #48
28	PISTON SLIPPER S/A	84	O-RING
29	SLIPPER RETAINER	85	BACK-UP RING
30	RETAINER PLATE GUIDE	86	CHECK VALVE S/A
31	CYLINDER BARREL DOWEL	87	POWER LIMITER VALVE
32	CYLINDER BARREL	88	SPRING
33	BEVELLED SPRING WASHER	89	O-RING
34	CYLINDER BARREL SPRING	90	PLUG, 22 FT-LB
35	FLAT SPRING SPACER	91	END COVER BOLT
36	INTERNAL RETAINING RING	92	END COVER BOLT
37	BARREL KIT		
38	BEARING PLATE		
39	ROTATING GROUP KIT		
40	VALVE PLATE		
41	SERVO PISTON S/A		
42	O-RING		
43	O-RING		
44A	SERVO SLEEVE		
44B	SERVO SLEEVE, ADJUSTABLE		
45	SET SCREW		
46	O-RING		
47	JAM NUT		
48	SERVO STOP SLEEVE		
49	SERVO LINK		
50	SERVO PISTON		
51	SERVO SPRING, LIGHT		
52	SERVO SPRING, HEAVY		
53	SERVO SPRING RETAINER		
54	SOCKET HEAD SCREW		
55	SOCKET HEAD CAP SCREW		
56	SERVO RETAINER		

